

# SCARPA® INNER BOOTS COLLECTION AND SUGGESTED TIME FOR HEATING FALL/WINTER 2019/2020



## ALPINE TOURING PERFORMANCE

**CROSS FIT PRO FLEX RIDE**  
10628-500/1

**MAESTRALE XT**

8-10 min



**CROSS FIT PRO FLEX PERFORMANCE**  
10629-501/1

**MAESTRALE RS**

8-10 min



**CROSS FIT PRO FLEX PERFORM. WMN**  
10629-502/1

**GEA RS**

8-10 min



**CROSS FIT PRO FLEX TOURING**  
10630-501/1

**MAESTRALE**

8-10 min



**CROSS FIT PRO FLEX TOURING WMN**  
10630-502/1

**GEA**

8-10 min



**PRO FLEX EVO G3**  
10612-501/2

**FLASH**

8-10 min



**PRO FLEX EVO G3 WMN**  
10612-502/3

**MAGIC**

8-10 min



## ALPINE TOURING TOUR LITE

**CROSS FIT TOUR**  
10623-500/1

**ALIEN RS**

4-6 min



**PRO FLEX EVO**  
10617-501/4

**F1**

6-8 min



**PRO FLEX EVO WMN**  
10617-502/4

**F1 WMN**

6-8 min



## ALPINE TOURING RACE

**CROSS FIT RACE 3.0 SL**  
10619-500/3\*

**ALIEN 3.0**

4-6 min



**CROSS FIT RACE 3.0 SL**  
10619-500/4

**ALIEN 3.0**

4-6 min



\* Liner with thicker padding

**CROSS FIT TOUR LITE**  
10627-500/1

**ALIEN**

4-6 min



**CROSS FIT BT**  
10626-500/1

**ALIEN 1.0**

4-6 min



## TELEMARK PERFORMANCE / CLASSIC

**SPEED PRO G**  
10611-501/5

**TX COMP/TX PRO**

8-10 min



**SPEED PRO G**  
10611-501/6

**T1**

8-10 min



**PERFORM. FLEX G**  
10608-501/4

**T2 ECO**

8-10 min



**CROSS FIT BC**  
10624-500/1

**T4**

6-8 min



**SPEED PRO G WMN**  
10611-502/4

**TX PRO WMN**

8-10 min



**PERFORMANCE FLEX G WMN**  
10608-502/3

**T2 ECO WMN**

8-10 min



## MOLDING OPERATIONS



### HEATING MACHINE

SCARPA® suggest to use only this type of heating machines for the molding of thermoformable inner boots. The temperature is already set, for the heating time follow the instructions on next page.

Suggested time for heating



### HEATING

Before heating be sure to remove any item from inside the liners. Insert the boots on the heating columns (do not remove the liner from the shell) and wait for the necessary time to heat the inner boots as indicated on next page.



### GET READY

To find out the correct size use the fit stick you find on the heating machine kit. Wear the stockings with the toe rubber cap in between.



### COOLING-OFF PERIOD

Wear the boots and set all closure systems without compressing the feet too much. If you feel any pressure point replace the liner or repeat the operation. Wait at least 7-8 minutes for the liners to cool down.